


URX725



1-01	Frame	1
1-02	Slide	1
1-03	Outer Barrel	1
1-04	Rail Mount	1
1-05	Grip	1
1-06	Internal Barrel	1
1-07	Pull Bar(R)	1
1-08	Trigger Connector Seat	1
1-09	Muzzle	1
1-10	Recoil Spring Guide	1

1-11	Sight Cover	1
1-12	Sight Seat	1
1-13	Rear Sight	1
1-14	Piston Seat	1
1-15	Trigger	1
1-16	Safety Parts	1
1-17	Trigger	1
1-18	Barrel Guide	1
1-19	Safety Catch	1
1-20	O-ring	1
1-21	Spring Bar	1
1-22	Axis	1
1-23	Axis	3
1-24	Axis	1
1-25	Axis	1

1-26	Screw	1
1-27	Adjusted Screw	1
1-28	Screw	1
1-30	Screw	2
1-31	Screw	1
1-32	Screw	1
1-33	Screw	1
1-34	Screw	2
1-35	Screw	1
1-36	Screw	1
1-38	Rear Sight Spring	1
1-39	Chamber Spring	1
1-40	Barrel Guide Spring	1
1-41	Rear Sight Spring	1
1-42	Trigger Connector Spring	1
1-43	Trigger Connector Spring	1
1-44	Pull Bar(L)	1
1-45	Pull Bar Connector	1
1-46	Piston Release Bar	1
1-47	Piston Chip	1
1-48	Internal Barrel	1
1-49	Axis	1
6-01	Chamber	1
6-02	Piston Rubber	1