



- |                           |                           |                                  |
|---------------------------|---------------------------|----------------------------------|
| 1. Recoil Spring          | 24. Grip Screw            | 47. Grip Hook Screw              |
| 2. Slide                  | 25. Right Grip            | 48. Grip Hook                    |
| 3. Hit Pin                | 26. Trigger Bar Spring    | 49. Left Grip                    |
| 4. Cylinder Block         | 27. Safety Spring         | 50. Valve Body Pin               |
| 5. Slide Screw            | 28. Safety                | 51. Frame Pin                    |
| 6. Hit Pin C-ring Clip    | 29. Hammer Pin            | 52. Magazine Catch               |
| 7. Trigger Spring         | 30. Hammer                | 53. Magazine Catch Spring        |
| 8. Trigger                | 31. Hammer Insert         | 54. Trigger Guard Pin            |
| 9. Trigger Bar            | 32. Barrel Base           | 55. Trigger Pin                  |
| 10. Valve Front Cap       | 33. Hammer Strut          | 56. Magazine                     |
| 11. Buffer O-ring         | 34. Main Spring           | 57. Slide Stop                   |
| 12. Feed Nozzle Spring    | 35. Hammer Strut Pin      | 58. Slide Stop Spring            |
| 13. Feed Nozzle           | 36. Puncture Screw Cover  | 59. Barrel Packing               |
| 14. Valve Body            | 37. Common Pin            | 60. Barrel C-ring Clip           |
| 15. Valve O-ring          | 38. Frame Pin             | 61. Inner Barrel                 |
| 16. Valve Washer          | 39. Main Spring Housing   | 62. Outer Barrel                 |
| 17. Valve Spring          | 40. Frame                 | 63. Trigger Guard Spring Housing |
| 18. Valve                 | 41. Puncture Screw        | 64. Hammer Block Piece Spring    |
| 19. Valve Seal            | 42. Puncture Nut Rear     | 65. Hammer Block Piece           |
| 20. Valve Rear Cap        | 43. Puncture Nut Front    | 66. Sear Spring                  |
| 21. Puncture Pin Assembly | 44. Trigger Guard Spring  | 67. Sear                         |
| 22. Face Seal             | 45. Trigger Guard Plunger | 68. Puncture Wrench              |
| 23. Puncture Pin Holder   | 46. Trigger Guard         | 101. Valve Assembly (No. 10~23)  |